




SPARE PARTS

No.	Part name	No.	Part name	No.	Part name
1	Backing Plate: GPT174 Backing plate (PSA) / GPT173 Backing plate (Hook & Loop)	15	Ball bearing 625-2RS	23	Spring 0.6 x 10 x 20
2	Screw M3 x 6	16	Outer runner motor-controller assembly	24	Housing (right)
3	Backing plate support – GPT175	17	Label	25	Screw ST3 x 18
4	Swing seat – GPT114	18	Housing (left)	26	Switch panel – GPT146
5	Holding ring – GPT115	19	Rubber pin	27	Panel support
6	Screw M4 x 6	20	Trigger – GPT123	28	Label
7	Bearing seat – GPT168	21	Location pin $\varnothing 2 \times 18$	29	Clip
8	Ball bearing 686Z	22	Magnetic steel D5 x 3.6	30	Battery – GPT125 *
9	Circlip for holes 13				
10	Screw M4 x 6				
11	Counterweight – GPT116				
12	Ball bearing 6001-2RS – GPT144				
13	Eccentric shaft – GPT139				
14	Armature – GPT157				

* Battery (**GPT125**) Sold Separately



fareclaproductsltd

Farécla | SURFACE FINISHING
SPECIALISTS