




NO. PART NAME

- 1 Applicator / pad
- 2 Backing plate
- 3 Output shaft M14
- 4 Screw M4 x 14
- 5 Gear case cover
- 6 Ball bearing 6201-2RS
- 7 6201 Bearing clamp
- 8 Screw M4 x 10
- 9 Circlip for shaft $\phi 12$
- 10 Side handle
- 11 Gear
- 12 Oil-impregnated bearing $\phi 12 \times \phi 8 \times 8$
- 13 Spindle-lock pin
- 14 Case plastic cover
- 15 Plastic screw M10 x 8
- 16 Lock pin cap
- 17 Pin spring
- 18 Screw ST4.2 x 40
- 19 Gear case
- 20 Screw M4 x 8
- 21 Gear shaft
- 22 Ball bearing 6200-2RS
- 23 Bevel gear Z2
- 24 Rubber seal ring
- 25 Bearing retainer
- 26 O-Ring 21.2 x 1.8
- 27 Ball bearing 608-DW
- 28 Armature 230V - **GPT130**
- 29 Magnetic Ring

NO. PART NAME

- 30 Ball Bearing 607-2RZ
- 31 Rubber Bearing Seat 607
- 32 Windshield
- 33 Screw ST4.2x70
- 34 Lead
- 35 Field Coil 230V
- 36 Field Coil Case
- 37 Data Label
- 38 Rear Handle (Upper)
- 39 Switch - **GPT124**
- 40 Trigger switch
- 41 Screw ST4.2x14
- 42 Cord Clamp
- 43 Cord Jacket
- 44 Power Cord with Plug
- 2-Pin - **GPT106**, or 3-Pin - **GPT112**
- 45 Screw ST4.2x16
- 46 Rear Handle (Lower)
- 47 Steel Sheet
- 48 Spring
- 49 Switch Lock Button
- 50 Controller Assembly 230V - **GPT118**
- 51 Screw ST2.9x8
- 52 Coil Spring
- 53 Carbon Brush Holder
- 54 Carbon Brush (pair) 230V - **GPT101**
- 55 Label
- 56 Speed Labeling
- 57 Wrench