


ST-DG1022L, ST-DG1026L

1/4"(6MM) ANGLE DIE GRINDER



PARTS LIST

No.	Parts No.	Description	Q'ty
1	DG1022L-01	Collet Nut	1
2	DG1022L-02	1/4" Collet [ST-DG1022L]	1
	DG1016L-02	6mm Collet [ST-DG1026L]	1
3	DG1022L-03	Spindle	1
4	DG1022L-04	Woodruff Key	1
5	DG1022L-05	Clamp Nut	1
6	DG1022L-06	Bearing (608ZZ)	2
7	DG1022L-07	Spinlde Gear	1
8	DG1022L-08	Retaining Ring	1
9	DG1022L-09	Angle Head Housing	1
10	DG1022L-10	Grease Fitting	1
11	DG1022L-11	Pinion	1
12	DG1022L-12	Coupling Nut	1
13	DG1022L-13	Lock Ring	1
14	DG1022L-14	Bearing (608ZZ)	1
15	DG1022L-15	Front End Plate	1
16	DG1022L-16	Bearing Space	1
17	DG1002L-17	Spring Pin (Φ2.5x20)	1
18	DG1002L-18	Valve Screw	1
19	DG1002L-19	O-Ring (ID9.19x2.62)	1
20	DG1002L-20	Valve Spring	1

No.	Parts No.	Description	Q'ty
21	DG1002L-21	Throttle Valve	1
22	DG1002L-22	O-Ring (P4)	1
23	DG1002L-23	Valve Shaft	1
24	DG1002L-24	Throttle Lever Assy	1
25	DG1002L-25	Spring Pin (Φ3x22)	1
26	DG1022L-26	Rotor	1
27	DG1022L-27	Spring Pin (Φ2.5x4)	3
28	DG1022L-28	Rear End Plate	1
29	DG1022L-29	Ball Bearing (696ZZ)	1
30	DG1022L-30	Cylinder	1
31	DG1022L-31	Rotor Blade	4
37	DG1022L-37	Spanner (#17)	1
38	DG1022L-38	Spanner (#11)	1
39	DG1022L-39	Washer	1
40	DG1022L-40	Washer	1
41	DG1002L-41	Housing	1
42	DG1002L-42	Muffler	2
43	DG1002L-43	O-Ring (S022.4)	1
44	DG1002L-44	Exhaust Sleeve	1
45	DG1002L-45	Inlet Bushing	1
46	DG1002L-46	Housing Cover	1