


3M™ Versaflo™ TR-800 Series

Parts and accessories



TR-800 Series



Part number	General description	Detailed description	Replace when maximum life is reached or when/if:
Starter Kits			
TR-819E	3M™ Versaflo™ TR-819E IS Starter Kit	Kit includes: Intrinsicly Safe TR-802E Powered Air Turbo, TR-830 Intrinsicly Safe Battery, TR-838 Battery Attachment Tool, BT-30 Length Adjusting Breathing Tube, TR-627 Easy Clean Belt, TR-6310E A2P Filter, TR-6300 Filter Cover, TR-641E Single Station Battery Charger Kit, TR-971 Airflow Indicator and TR-6600 Prefilter (x10)	Replace component(s) in kit based on guidance in table below, and/or reference component user instructions
TR-819UK	3M™ Versaflo™ TR-819UK IS Starter Kit	Kit includes: Intrinsicly Safe TR-802E Powered Air Turbo, TR-830 Intrinsicly Safe Battery, TR-838 Battery Attachment Tool, BT-30 Length Adjusting Breathing Tube, TR-627 Easy Clean Belt, TR-6310E A2P Filter, TR-6300 Filter Cover, TR-641UK Single Station Battery Charger Kit, TR-971 Airflow Indicator and TR-6600 Prefilter (x10)	Replace component(s) in kit based on guidance in table below, and/or reference component user instructions
Turbo			
TR-802E	3M™ Versaflo™ TR-802E Intrinsicly Safe Powered Air Turbo	Replacement Blower for Versaflo™ TR-800 (includes TR-971 Air Flow Indicator)	Damaged or unable to resolve alarms
Component Parts			
TR-626	Belt	High Durability belt for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged
TR-627	Belt	Easy Clean belt for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged
TR-627X	Belt extender	Belt extender for TR-627 Easy Clean Belt	Damaged
TR-830	Battery	Standard battery for Versaflo™ TR-800 Powered Air Turbo	Damaged or no longer achieving desired run-time
TR-838	Battery attachment tool	Battery attachment tool for Versaflo™ TR-800 Powered Air Turbo and TR-800 battery	Damaged
TR-640	Charger	Replacement charger cradle for TR-641/TR-644 kits (not shown)	Damaged, broken, or unable to charge battery
TR-641E/UK	Charger	Single-bay charger kit for Versaflo™ TR-600/TR-800 batteries	Damaged, broken, or unable to charge battery
TR-644E/UK	Charger	4-bay charger kit for Versaflo™ TR-600/TR-800 batteries	Damaged, broken, or unable to charge battery
TR-6600	Prefilter	Prefilter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged or clogged
TR-6710E	Filter	Particulate Filter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged or when change is indicated by the Powered Air Turbo low flow alarm
TR-6820E	Filter	Particulate/Nuisance Odour* filter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged, when change is indicated by the Powered Air Turbo low flow alarm or when nuisance odor relief is no longer provided
TR-6110E	Filter	A1P Filter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged, when change is indicated by the Powered Air Turbo low flow alarm, when indicated by service life software, or if breakthrough is detected
TR-6310E	Filter	A2P Filter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged, when change is indicated by the Powered Air Turbo low flow alarm, when indicated by service life software, or if breakthrough is detected
TR-6130E	Filter	ABE1P Filter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged, when change is indicated by the Powered Air Turbo low flow alarm, when indicated by service life software, or if breakthrough is detected
TR-6580E	Filter	ABE2K1HgP Filter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged, when change is indicated by the Powered Air Turbo low flow alarm, when indicated by service life software, or if breakthrough is detected
TR-6700FC	Filter cover	Filter cover for 6700 series filter for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged or broken. No longer securely attaches to filter
TR-6800FC	Filter cover	Filter cover for 6800 series filters for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged or broken. No longer securely attaches to filter
TR-6300FC	Filter cover	Filter cover for 6300 series filter/cartridge for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged or broken. No longer securely attaches to filter
TR-6500FC	Filter cover	Filter cover for 6500 series filter/cartridge for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged or broken. No longer securely attaches to filter
TR-971	Flow indicator	Air Flow indicator for Versaflo™ TR-600/TR-800 Powered Air Turbos	Damaged
TR-851	Filter latch	Replacement filter latch assembly for TR-802E Powered Air Turbo	Damaged
TR-653	Cleaning/storage kit	Cleaning and Storage Kit for Versaflo™ TR-600/TR-800 Powered Air Turbos and TR-630/TR-632/TR-830 batteries	Damaged, broken, gaskets changed after 30 washings
TR-654	Cleaning/storage kit	Replacement gaskets for TR-653 cleaning and storage kit	Damaged, broken, gaskets changed after 30 washings
BPK-01	Backpack	Backpack for Versaflo™ TR-600/TR-800 Powered Air Turbos (not shown)	Damaged
TR-655	Backpack adaptor	Backpack Adaptor to connect Versaflo™ TR-600/TR-800 to BPK-01 (not shown)	Damaged
TR-329	Braces	Braces for use with any Versaflo belts (not shown)	Damaged
BT-30	Breathing tube	Length adjusting breathing tube to connect Versaflo™ TR-600/TR-800 Powered Air Turbos to Versaflo™ family of Soft and Rigid headtops (not shown)	Damaged, broken, holes, cuts or tears

* Nuisance Odour refers to concentrations below the threshold limit value.